

# Bra Form Sizing Guide

		Bra Size																
		28	30	32	34	36	38	40	42	44	46	48	50	52				
Cup Size	AA	inch 60	30 65	32 70	34 75	36 80	38 85	40 90	42 95	44 100	46 105	48 110	50 115	52 120				
	A	inch 60	28 60	30 65	32 70	34 75	36 80	38 85	40 90	42 95	44 100	46 105	48 110	50 115	52 120			
	B	inch 60		28 60	30 65	32 70	34 75	36 80	38 85	40 90	42 95	44 100	46 105	48 110	50 115	52 120		
	C	inch 60			28 60	30 65	32 70	34 75	36 80	38 85	40 90	42 95	44 100	46 105	48 110	50 115	52 120	
	D	inch 60				28 60	30 65	32 70	34 75	36 80	38 85	40 90	42 95	44 100	46 105	48 110	50 115	52 120
	DD	inch 60					28 60	30 65	32 70	34 75	36 80	38 85	40 90	42 95	44 100	46 105	48 110	50 115
	DD	inch 60						28 60	30 65	32 70	34 75	36 80	38 85	40 90	42 95	44 100	46 105	48 110
Breast Forms																		
401 Harmony Triangle		1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17
402 Harmony Plus Triangle		1	2	3	4	5	6	7	8	9	10	11	12	13	14			
403 Harmony Teardrop		1	2	3	4	5	6	7	8	9	10	11	12	13	14			
404 Harmony Profile		1	2	3	4	5	6	7	8	9	10	11	12	13	14			
405 Harmony A Supreme		1	2	3	4	5	6	7	8	9	10	11	12	13	14			
406 Harmony Connect		1	2	3	4	5	6	7	8	9	10							
407 Harmony Flex		1	2	3	4	5	6	7	8	9	10	11	12	13	14			
408 Harmony Xtend		1	2	3	4	5	6	7	8	9	10	11	12	13	14			
933 SoLight		1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17
955 Supreme Light				3	4	5	6	7	8	9	10	11	12	13	14			
988 Serene Light				3	4	5	6	7	8	9	10	11	12	13	14	15	16	17
561 Impressa		1	2	3	4	5	6	7	8	9	10	11	12	13	14			
633 Symphony			1	2	3	4	5	6	7	8	9	10	11	12	13	14		
733 Symphony Encore					3	4	5	6	7	8	9	10	11	12	13	14		
722 Symphony Light						5	6	7	8	9	10	11	12	13	14			
344 E Supreme		1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17
511 Le Coeur			1	2	3	4	5	6	7	8	9	10	11	12				
333 A Supreme		1	2	3	4	5	6	7	8	9	10	11	12	13	14			
505 Classic			0	1	2	3	4	5	6	7	8	9	10	11	12			
Post-Surgery & Leisure																		
922 Calypso Swim Form					3	4	5	6	7	8	9	10	11					
641 Tropez Swim Form					3	4	5	6	7	8	9	10	11					
615 Featherweight		1	2	3	4	5	6	7	8	9	10	11	12	13	14			
616 Tri-Featherweight		1	2	3	4	5	6	7	8	9	10	11	12	13	14			
611 Tri-Leisure				3	4	5	6	7	8	9	10	11	12	13	14			
44 Leisure Form				3	4	5	6	7	8	9	10	11	12	13	14			
Partial Forms																		
533 Triangle Partial				3	4	5	6	7	8	9								
531 Teardrop Partial		1	2	3	4	5	6	7	8	9	10	11						
810 / 812 Secrets		Correct size is dependent on breast size and desired effect.																
814 Little Secrets		Correct size is dependent on breast size and desired effect.																

This is to be used as a guide. You may need to try more than one size or style to assure proper fit.